

# **ADVANCED AEROSOL SAMPLING TECHNOLOGIES FOR POINT BIODETECTION**

**Dr. Edward W. Stuebing**

**Dr. Jerold Bottiger**

**US Army Edgewood Chemical Biological Center**

**Aberdeen Proving Ground, MD 21010**


CB Defense Conference 2004 15-17 Nov 04

Report Documentation Page				Form Approved OMB No. 0704-0188	
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE <b>17 NOV 2004</b>		2. REPORT TYPE <b>N/A</b>		3. DATES COVERED <b>-</b>	
4. TITLE AND SUBTITLE <b>Advanced Aerosol Sampling echnologies For Point Biodefetection</b>				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) <b>US Army Edgewood Chemical Biological Center Aberdeen Proving Ground, MD 21010</b>				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT <b>Approved for public release, distribution unlimited</b>					
13. SUPPLEMENTARY NOTES <b>See also ADM001849, 2004 Scientific Conference on Chemical and Biological Defense Research. Held in Hunt Valley, Maryland on 15-17 November 2004., The original document contains color images.</b>					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT <b>UU</b>	18. NUMBER OF PAGES <b>36</b>	19a. NAME OF RESPONSIBLE PERSON
a. REPORT <b>unclassified</b>	b. ABSTRACT <b>unclassified</b>	c. THIS PAGE <b>unclassified</b>			

# **DISCLAIMER**

The use of either trade or manufacturers' names in this report does not constitute an official endorsement of any commercial products. This report may not be cited for purposes of advertisement.

# Trigger vs. Collector




# Example Biodetection Systems

Trigger Inlets & Collector Inlets

**BIDS**




**JBPDS**



**INLET**  
**Large particle remover**  
**Multi-stage CONCENTRATOR**  
**COLLECTOR**




# Typical Aerosol Sampling System



# Aerosol Particle Behavior

- Settling
- Impaction



## TAKE-HOME MESSAGE:

Aerosols are NOT gases.


Their inertia gives us a handle on them.

Their inertia can confound our efforts to transport them.

Material is sparsely distributed in space.

# Particle Settling in Still Air

Time to settle 5 feet by unit density spheres




Sampling trains are usually vertical and avoid bends, horizontal.  
- requires size dependent characterization over 1-10 micron.



# Particle Settling in Still Air

Time to settle 5 feet by unit density spheres



# Both Large and Small Sizes are Difficult to Sample with High Efficiency


1  $\mu\text{m}$



3  $\mu\text{m}$




10  $\mu\text{m}$



Too little inertia –  
impactor  
concentrators and  
collectors require  
high acceleration

Typical sampler efficiency  
data



Too much inertia –  
difficult to aspirate  
and transmit through  
tubing to collector  
without wall losses

# Aerosol Sampler Technology Challenges

## Description

Provide  
advanced  
collectors  
and inlets

---

- smaller
- lighter
- less power
- inexpensive
- sub-freezing
- higher  
concentration  
liquid sample

## Goals

- High efficiency inlets for 1-10 micron particles and wind speeds (stationary outdoors up to 15-20 mph, HVAC up to 25 mph, vehicles/ships maybe 60 mph?)
- High efficiency, low power aerosol concentrator for 1-10 micron particles
- Low temperature (range of US cities) aerosol collector for wet samples
- Dry aerosol collectors
- Triggered vs. Long term “sentinel” wet and dry aerosol collectors
- Viability-preserving aerosol collectors

# Aerosol Sampler Performance Issues

- Detection Sensitivity (collected amount and concentration)
  - Air flow rate (sample size vs. time)
  - Collection Efficiency (particle size dependent – 1-10 micron)
  - Reject unwanted sizes, e.g., pollens
    - background suppression, dust
  - Concentration factor (into liquid or air)
- Utility
  - Rise time, Clear down time
  - Low & high temperature
    - wet collectors
    - dimensional stability, air viscosity
  - Clean up/Decon
- Logistics
  - Power consumption (incl. low temps)
  - Size & Weight (portability)
  - Liquid requirement (recirculating?)
  - Rugged, reliable, maintainable (lab devices unsuitable in field)

# Bio Detection Systems

## Aerosol Sampling Subsystem

Inlet  
Fractionator  
Aerosol  
Concentrator  
Wet Collector  
Dry Collector

SAMPLE



Vol  
Conc

Size  
Amount


## Biological Analysis Subsystem

Optical Trigger  
Immunoassay  
PCR  
Sample Prep  
Mass Spec  
Py-GC-IMS/MS  
MALDI MS

# Bio Detection Systems

## Aerosol Sampling Subsystem

## Biological Analysis Subsystems



# Advanced Aerosol Sampling Technologies

Conventional  
Inertial

Improved large particle rejection

Shrouded probes (for wind, moving platforms, or HVAC ducts)

Next  
Generation  
Inertial

Low power inertial  
concentrators

Low power, low  
temp wet collector

Non-inertial  
Technologies

Electrostatic concentrator/collector

Impeller collectors

Micro array dry collector

Hydrosol Concentrator

Acoustic concentrator

Power example

~500W

~150W

<100W

40 - 20W

<10W

FY04  
Technology

Future Capabilities →


# **EXAMPLES OF ADVANCED SAMPLING TECHNOLOGIES**

**CAVEAT:** The following examples are given to illustrate each of the advanced aerosol sampling technologies currently being explored. This is not intended to be a complete catalog of all the applications of these technologies under development.



# **CONVENTIONAL INLET**

## **heavy dust penetrates the fractionator**




# **CONVENTIONAL INLET WITH OILED PAD**


**oiled pad improves fractionator for retaining large particles such as dust**



**Inlet Efficiency as Function of Wind Speed**  
**Various Particle Sizes for an ~100 LPM Omnidirectional Inlet**



# SHROUDED PROBE INLET




# Large Shrouded Probe Inlet

## 1,000 lpm Class Shrouded Probe




## Comparison of Shrouded Probe & Conventional Omnidirectional Collector Inlet Performance 8 micron particles




# Shrouded Probe Inlet

- Shrouded probe inlet is superior at high wind conditions when pointing into wind, for example, in HVAC ducts.
- Yaw angle performance is good at low wind conditions. Sampling when wind is coming from side is not degraded considerably when compared with a simple omnidirectional inlet.
- Application: Shrouded Probe might replace omnidirectional inlets in outdoor situations and enhance windy and moving-platform performance without seriously degrading performance. (Full range of wind speeds and particles sizes remains to be studied.)



**Yaw Angle Performance of 100 l/m Shrouded Probe**  
**Test Condition: 6 micron particles at 8 miles per hour**





# New Concentrators Under Testing

**mini slits process small particles with low pressure drop**




Test Bed  
for mini-  
slit design




High flow (3,000+ lpm)  
Virtual Impactor Concentrator  
using a large horizontal  
array of mini-slits

# New Aerosol Collector using mini-jets to capture small particles with low pressure drop


Energy Efficient  
Low Temperature Wet Collector




Fractional Efficiency Curve



Response Time of the AHTS








# Electrostatic Collection


*...versatile technology capable of interfacing to many detection systems...*



# Compact Electrostatic Aerosol Concentrator

*...capabilities: compact, low power, high flow rate...*

- **Direct aerosol concentration without energy consumptive inertial separation process upstream**
  - Pressure drop orders of magnitude lower than inertial separation collector
  - Multi-unit samples >200 LPM with 1 watt fan
- **Integrated high efficiency corona charger & collector for minimal size**
- **Particles deposited into small volume of liquid (< 1 ml)**
- **Low cost – low weight injection molded plastic construction**







# Electrostatic Radial Collector Performance

*...original configuration vs. high density array data...*


**Electrostatic deposition of 2.3  $\mu$  beads onto a 0.125 in. diameter dry post from 0.75 in. diameter duct**



**Electrostatics Off**




**High Density  
Corona Array  
Collection Efficiency  
>85% @ 30 lpm**



**Electrostatics On**

**Original  
Configuration  
Corona Array  
Collection Efficiency  
>50% @ 30 lpm**




This presentation is subject to the rights and limitations as stated within Government Contracts No. DAAD13-03-C-0041 and No.W911SR-04-C-0025."

# IMPELLER EXAMPLE




## ROTATING ARM COLLECTOR

BioCapture Air Sampler






# Micropillar Array Dry Collector



A low pressure drop, high flow filter with collection efficiency of a good aerosol collector (80-90%).

# Particle Trajectories Through three rows of offset rectangular micropillars




**Figure 1.** (a) Pressure Drop and droplet trajectories (b) Velocity Profile corresponding to an inlet velocity of 5 m/s and for particles of  $1 \mu\text{m}$  size with a 5V voltage potential.

# Micropillar Results



Aerosol Capture on  
**Uncoated** Micropillars  
at 1'' Water Pressure  
Drop: 1-Micron PSL




Aerosol Capture on  
**Coated** Micropillars  
at 1'' Water Pressure  
Drop: 1-Micron PSL



# Example Hydrosol Concentrator

## Two-Level Designs using dielectrophoresis (DEP)




### UNIFORM FIELD DESIGN:


- 1) Electrochromatography:  
Dispersion Minimization
- 2) Particle Filtration:  
Bandwidth Minimization

# Simulation of particles sliding along ridge and out tube (forked splitter)


No DEP




With DEP




With DEP  
(Animation)




# Forked Splitter Results (*Bacillus subtilis*)



5 V



250 V





500 V

# ACOUSTIC CONCENTRATION IN AEROSOL FLOW

Particle Trajectories

Video of Exit Flow



# ACKNOWLEDGEMENTS

This presentation would not have been possible without the research accomplishments and the generous contribution of PowerPoint presentation materials from the following organizations:

Lawrence Livermore National Laboratory

MicroEnergy Technologies, Inc.

MesoSystems, Inc.

NIOSH

Sandia National Laboratory

Sarnoff Corporation

Texas A&M University

University of Texas Applied Research Laboratory

University of Idaho

US Army Edgewood Chemical Biological Center